

# ACCENT

model  
**SHOT**



Kolor soczewek / lens color

lustrzane (niebieskie, pomarańczowe, czerwone, szare) / mirror (blue, orange, red, grey)

bezbarwne / transparent  
żółte / yellow

rozjaśniające (niebieskie, różowe) / brightening (blue, pink)

fotokromy / photochromic

Kat. filtru / filter cat.

3

0

2

0/3

Filtr UV400

Środek ochrony indywidualnej kat. „I”  
ENISO1 231 2-1:2013

Śledź nas na | Follow us on:

@ACCENTBIKES

@ACCENTBIKES

[www.accent-bikes.com](http://www.accent-bikes.com)



Producent: Velo sp. z o. o.  
ul. Pszczyńska 305, 44-100 Gliwice, PL  
[www.velo.pl](http://www.velo.pl)

PL

## JAK CZYŚCIĆ I PRZECHOWYWAĆ TWOJE OKULARY?

- Aby wyczyścić soczewki z tłustych plam lub odcisków palców użyj miękkiej szmatki lub wody z mydłem. Uważaj przy tym, by szmatka nie była zabrudzona lub ostra!
- By usunąć kurz czy ziarenka piasku przemyj soczewki strumieniem wody i pozostaw do wyschnięcia.
- Okulary należy chronić przed ekstremalnymi różnicami temperatur i przechowywać w pokrowcu lub etui. Przed użyciem upewnij się czy okulary nie zostały uszkodzone, a soczewki porysowane lub zabrudzone, gdyż może to pogorszyć widoczność.
- Okres trwałości ramek i soczewek: bezterminowo, do czasu fizycznego zniszczenia.
- Produkt nie chroni przed sztucznymi źródłami światła (np. solarium) oraz nie zapewnia ochrony przed mechanicznymi skutkami wypadków.
- Produkt nie nadaje się do bezpośredniego obserwowania słońca.

**Pamiętaj, aby demontaż zaczynać zawsze od środkowej części okularów.**

## JAK WYJMOWAĆ SOCZEWKI?

1. Chwyć okulary za środek soczewki i wciśnij element mocujący górnej części oprawki. (RYS. A)
2. Chwyć okulary za brzeg soczewki i wyciśnij element mocujący górnej, bocznej części oprawki. Powtórz czynność dla drugiego ramienia. (RYS. A)
3. Chwyć okulary za brzeg soczewki i wyciśnij element mocujący dolnej, bocznej części oprawki. Powtórz czynność dla drugiego ramienia. (RYS. B)

## JAK ZAKŁADAĆ SOCZEWKI?

1. Włóż krawędź soczewki w środkową, dolną część oprawki z noskiem i wciśnij element mocujący. (RYS. C)
2. Włóż krawędź soczewki w boczną, dolną część oprawki. Dociśnij krawędź. Powtórz dla drugiej strony oprawki. (RYS. C)
3. Włóż krawędź soczewki w boczną, górną część oprawki. Dociśnij krawędź. Powtórz dla drugiej strony oprawki. (RYS. D)
4. Włóż krawędź soczewki w środkową, górną część oprawki. (RYS. D)

ENG

## HOW TO CLEAN AND STORAGE YOUR GLASSES?

- To clean the stains or fingerprints off the lenses, please use a soft cloth or water and soap. Do not use a cloth which may be dirty or may destruct the lenses.
- If there is dust or sand on the lense surface, rinse it with water and leave for dry.
- Protect your glasses from extreme temperature differenes. Use a special case or a microfiber bag to store the glasses. Before the use make sure the lenses are not cracked or dirty, which may reduce visibility.
- Lifespan of the lens holder and lenses: indefinite, till they are physically worn out.
- The product does not protect against artificial light sources (e.g., solariums) and does not provide protection against the mechanical effects of accidents.
- Not suitable for direct observation of the sun.




**Remember to always start disassembly from the middle of the glasses.**

## HOW TO REMOVE LENSES?

1. Grasp the glasses by the center of the lens and push out the upper part of the lens holder. (FIGURE A)
2. Hold the glasses by the edge of the lens and press the top-side part of the lens holder. Repeat the same move to the other side of the holder (FIGURE A)
3. Hold the glasses by the edge of the lens and press on the bottom-side part of the lens holder. (FIGURE B)

## HOW TO INSTALL LENSES?

1. Insert the edge of the lens into the middle-lower part of the lens holder with nose cone and press on the retainer. (FIGURE C)
2. Insert the edge of the lens into the side-bottom part of the holder. Press down on the edge. Repeat the same move to the other side of the holder. (FIGURE C)
3. Insert the edge of the lens into the top-side part of the holder. Press down on the edge. Repeat the same move to the other side of the holder. (FIGURE D)
4. Insert the edge of the lens into the middle-top part of the holder. Press down on the edge. (FIGURE D)



MIEJSCE TRZYMANIA / HOLDING AREA  
 KIERUNEK WYCIĄGANIA SOCZEWKI / OPRAWEK / DIRECTION OF LENS/HOLDER REMOVAL  
 MIEJSCE ODGIĘCIA/WYPCHANIA / BENDING / PUSHING OUT AREA